Work Order II	) 60959
---------------	---------

July 29, 2010 1:07:37 PM

105

Packaging

Packaging

Pick Kit

Memo



Page 1

Item ID: D120-639-011 Accept Setup Start **Revision ID:** Stop Tungsten Carbide Wearplate Item Name: **Start Date:** 7/29/10 Start Qty: 2.00 Cust Item ID: Required Date: 7/29/10 Req'd Qty: 2.00 Customer: Reference: Run Start **Process Plan: Approvals:** Date: **Tooling:** Date: Stop QC: SPC (Y/N): Date: Date: Sequence ID/ Operation Set Up/ Tool # Plan Reject Reject **Tool ID** Accept Insp. **Work Center ID** Description Code Qty Qty Stamp **Run Hours** Number Draw Nbr **Revision Nbr** DSI 9223 Rev A IIN-D120-639 Rev A 100 0.00 DOCUMENT CONTROL 0.00 Memo Document Control Photocopy bluefile and type labels per PPP D120-639-011 CHG 002 8 13/02/30

0.00

0.00

## Work Order ID 60959

July 29, 2010 1:07:37 PM

Required Date: 7/29/10



Page 2

Item ID:

D120-639-011

Accept

Setup Start

Stop



**Revision ID:** 

Item Name:

Tungsten Carbide Wearplate

**Start Date:** 

7/29/10

Start Oty: 2.00

Req'd Qty: 2.00



**Cust Item ID:** 

**Customer:** 

Reference:

Approvals:

Process Plan:

QC: \_\_\_\_ Date:

Date:

Tooling: SPC (Y/N): Date: Date:

Start Run

Stop



Sequence ID/

Work Center ID 110

Quality Control

Operation **Description** 

QC4-100% Inspect kits for completeness

Memo

Set Up/ **Run Hours** 

0.00 Sida/30

Tool ID

Tool # Plan Code

Accept Qty

Reject **Qty** 

Reject Number

Stamp

120

Packaging

Packaging

Packaging

0.00

0.00

Package and Identify as per PPP D120-639-011

130

Quality Control

QC21- Final Inspection - Work Order Release

0.00

Memo

0.00

10/08/03/18) MF 10-8-03

July 29, 2010 1:07:35 PM

Work Order ID: 60959

Parent Item:

D120-639-011

Parent Item Name: Tungsten Carbide Wearplate



Start Date: 7/29/10

Start Qty: 2.00

Required Date: 7/29/10

Page 1

Required Qty: 2.00

	Comments:	PP D 02.09.	13 Re-format, Ac	ided M	S27130-S30	KJ								
	Component Item ID/ Item Name	Replacement Item ID	Mfg/ Purch	Bin Item	Primary Location	Last Location	Route Seq ID	Unit of Measure	Qty on Hand	Qty per Kit	Total Qty	Qty Issued	Date Issued	Status
. ~	D2746  Wearshoe		Manufactured	No			105	Each	12.0000	· 1	<sup>2</sup> /U/7	130.0	en er ogen er gen	
					<b>Location</b> ST496A		Loc	Otv	Loc Code	·		_		
ìa	D2656-31		Manufactured	No		46960	105	12 Each	2.0000		1/2/30		ρ	F ## · ·
					<u>Location</u> MEZZ	44119	<u>Loc (</u>	Oty 2 1	Loc Code	- <del>4</del>	<b>a</b>	_	ļ	
ฤ	D2656-13		Manufactured	No	***************************************		105	Each ;	13.0000		17/30	- - - -		: <b>→</b> ⊷ ···
					Location		Loc (	<u>Oty</u>	Loc Code				\	i
					FP020			11		_		_		
						57354		11 '			4	_		
					FP20	55454		2		Ä	<u>.                                    </u>	_		•

**Picklist Print** 

July 29, 2010 1:07:35 PM

Work Order ID: 60959 D120-639-011 Parent Item: Parent Item Name: Tungsten Carbide Wearplate Required Date: 7/29/10 **Start Date: 7/29/10** Start Qty: 2.00 Required Qty: 2.00 ALS7-1032-130 105 Each 950.0000 Purchased No Location Loc Qty Loc Code FP 933 933 115079 ST282 17 113238 17 D2648-3 Manufactured No 105 Each 50.0000 Wearpad Location Loc Qty Loc Code FG 12 12 45316 FP17 38 57516 8 59595 30 105 Purchased No Each 1,843.000 Screw Location Loc Code Loc Qty ST291 1843 110835 643 114718 200 115108 1000 NAS1149D0332J Purchased AN960JD10L No 105 Each 2,845.000 Location Loc Qty Loc Code ST348 2845 110985 2845 July 29, 2010 1:07:35 PM **Shop Packet Print** Page 2

# **Picklist Print**

July 29, 2010 1:07:35 PM

Work Order ID: 60959

Parent Item:

D120-639-011

Parent Item Name: Tungsten Carbide Wearplate

MS27130-S30

Purchased

No

105

Each

Start Date: 7/29/10

Required Date: 7/29/10

Page 3

Start Qty: 2.00

Required Qty: 2.00

248.0000





Location ST293

100154

248

Loc Qty

248

Loc Code

July 29, 2010 1:07:35 PM

**Shop Packet Print** 

Page 3



### 32.2 WEIGHT AND BALANCE

The following weight and balance information is for the Dart wearplate kits that are being installed. The weight and balance of any wearplates that are being removed from the aircraft is the responsibility of the installer.

	Mainh	LAT	ERAL	LONGITUDINAL		
Installation	Weight	Arm Moment		Arm	Moment	
D120-639-011	3.1 lb	136.0 in	422 in lb	±40.7 in	±126 in lb	
TUNGSTEN CARBIDE WEARPLATE KIT	1.4 kg	3.45 m	4.8 m kg	±1.04 m	±1.5 m kg	
D120-639-013	4.1 lb	136.0 in	558 in lb	±40.7 in	±167 in lb	
SURFACITE™ WEARPLATE KIT	1.8 kg	3.45 m	6.2 m kg	±1.04 m	±1.9 m kg	

#### 32.4 PARTS LIST

Qty -01.1	Qty -013	Part Number	Description
-0 1/1	-013		
X		D120-639-011	TUNGSTEN CARBIDE WEARPLATE KIT
	X	D120-639-013	SURFACITE <sup>™</sup> WEARPLATE KIT
1	1	D2746	WEARPLATE
1	1	D2656-31	WEARPLATE
1	1	D2656-13	WEARPLATE
5		D2648-3	WEARPAD
~ ~	5	D2648-7	WEARPAD
40	40	ALS7-1032-130	INSERT
		or AKS7-1032-130 -	
•		or ALS4-1032-130	
	_	or AKS4-1032-130	
40	40	MS27039-1-08	SCREW
40	40	AN960JD10L	WASHER
	The state of the s		



DESIG	<b>*</b>	DRAWN BY	DART AEROSPA HAWKESBURY, ONTARK	
CHECKED APPROVED		APPROVED	DRAWING NO.	REV. A
	1	#	DSI 9223	SHEET 1 OF 1
DATE			TITLE	SCALE
01.1	1.19		WEARPLATE INSERTS	NTS
Α		01.11.19	NEW ISSUE	

# **DART SERVICE INSTRUCTION**

TO AMEND INSTALLATION INSTRUCTIONS IIN-D120-639 Rev. A

REF. CANADIAN STC SH01-25 FAA STC: SR01347NY


REPLACE (4) AFTMOST ALS7-1032-130 INSERTS WITH (4) RNS1032-330 / MS27130-S30 INSERTS. UPDATE PARTS LIST AS FOLLOWS ENERGY.

**REPLACE:** 

QTY -011	QTY -013	Part Number	Description
40	40	ALS7-1032-130	INSERT

WITH:

QTY -011	QTY -013	Part Number	Description
36	36	ALS7-1032-130 \	INSERT
: 4 4		RNS1032-330 or MS27130-S30	INSERT



OF Ø0.297 FOR THESE 4 INSERTS

CANADA
DEPARTMENT OF TRANSPORT
AIRCRAFT CERTIFICATION
BRANCH
DAO # 01-0-01

APPROVED

D. SHEPHERD (DE # 02)

DATE: NOV 19, 2001
CERT. NO.: SH01-25
ISSUE NO.: 1

Copyright © 2001 by DART AEROSPACE LTD

THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE LTD.